









Protocol	#5.3
Title	BOMB plasmid DNA extraction using Sera-Mag carboxylated beads
Keywords	HT DNA miniprep, Sera-Mag, plasmid extraction
Authors	Treitli S. C.
Citation	<i>Treitli S.C., BOMB.bio, 2019</i>
Online	https://bomb.bio/protocols/
Editing	V1.0 (Oberacker P., 16 th September 2019)

Chemicals

Name	Provider	PN	MW [g/mol]	Safety codes	
Acetic acid (CH₃COOH)	Merck	1.09951	60.05	 Danger	H: 290-314 P: 280-301+330+331-305+351+338-308+310
Ethanol (C₂H₆O, 99.9%)	Honeywell / Riedel-de Haën	34963	46.07	 Danger	H: 225-319 P: 210-280-305+351+338-308+313
Ethylenediaminetetraacetic acid dihydrate / EDTA (C₁₀H₁₆N₂O₈ · 2 H₂O)	Roth Chemicals	8043.1	372.24	 Warning	H: 332-373 P: 260-314
Hydrochlorid acid fuming (HCl_(aq), 37%)	Roth Chemicals	4625.2	36.46	 Danger	H: 290-314-335 P: 280-303+361+353-304+340-305+351+338-310
Polyethylene glycol 8000	AppliChem	A2204	~8000	n.a.	n.a.
Potassium acetate (CH₃CO₂K)	Riedel-de Haën	32309	98.15	n.a.	n.a.
RNase A	Serva	34390.02	n.a.	 Danger	H: 334 P: 261-284-304+340-342+311
Sodium Chloride (NaCl)	Roth Chemicals	3957.2	58.44	n.a.	n.a.
Sodium dodecyl sulfate / SDS (C₁₂H₂₅NaO₄S)	Roth Chemicals	CN30.3	288.38	 Danger	H 302-315-318-412 P: 280-301+312-302+352-305+351+338-332+313

Name	Provider	PN	MW [g/mol]	Safety codes	
Sodium hydroxide (NaOH)	Roth Chemicals	6771.2	40.00	 Danger	H: 290-314 P: 280- 301+330+331- 305+351+338- 310
Tris(hydroxymethyl)- aminomethane / Tris (C ₄ H ₁₁ NO ₃)	Roth Chemicals	AE15.3	121.14	 Warning	H: 315-319-335 P: 280-302+352- 305+351+338- 312
Tween 20	Roth Chemicals	9127.1	1228	n.a.	n.a.

Please consult appropriate MSDS information before working with these chemicals! Use lab coat, gloves and eye protection at all times! The chemicals are available from other providers as well. No preference is given to the indicated vendors.

Buffers and solutions

1 M Tris (50 ml)

6.057 g – TRIS

40 ml of MilliQ water

Adjust the pH to 8.0 with concentrated HCl

Bring the final volume to 50 mL

Filter sterilize.

0.5 M EDTA (50 ml)

9.31g – EDTA

40 ml of MilliQ water

Adjust the pH to 8.0 NaOH. You will need around one gram of NaOH. When you get close to pH 8, it is better to use NaOH solution, to avoid overshooting the pH.

Bring the final volume to 50 mL.

Filter sterilize.

1 M NaOH (50 ml)

2g -NaOH

Dissolve in 40 ml of MilliQ water.

Bring the final volume to 50 ml

P1 buffer – can be stored at 4 °C for up to 12 months

Reagent	Concentrations	For 50 ml
Tris-HCl pH 8.0	50 mM	2.5 ml of 1 M stock
EDTA	10 mM	1 ml of 0.5 M stock
RNAseA	200 µg/ml	100µl from a 100mg/ml stock

adjust the volume with MilliQ water to 50 ml

P2 buffer – can be stored at RT for up to 12 months

Reagent	Concentrations	For 50 ml
NaOH	200 mM	10 ml of 1 M stock
SDS	1%	0.5 g

adjust the volume with MilliQ water to 50 ml

P3 buffer – can be stored at RT for up to 12 months

Reagent	Concentrations	For 50 ml
Potassium acetate	2.3 M	11.3 g

Add water till you have around 30 ml solution. Adjust the pH of the solution to **4.8** using **acetic acid**. Afterwards adjust the volume with MilliQ water to 50 ml

PB buffer – can be stored at 4 °C for up to 12 months

Reagent	Concentrations	For 50 ml
NaCl	2.5 M	25 ml of 5 M stock
Tris-HCl pH 8.0	10 mM	0.5 ml of 1 M stock
EDTA	1 mM	0.1 ml of 0.5 M stock
PEG 8000	20%(w/v)	10g
Tween 20	0.05%	0.25 ml of 10% stock
Sera-Mag carboxylated beads	1.14% (v/v)	570 µl of stock (wash first, see below)

adjust the volume with MilliQ water to 50 ml

PE buffer – can be stored at RT for up to 12 months

Reagent	Concentrations	For 50 ml
Tris-HCl pH 7.5	10 mM	0.5 ml of 1 M stock
Ethanol	80 %	41.7 ml of 96% EtOH
MilliQ water	N/A	7.8 ml

EB buffer – can be stored at RT for up to 12 months

Reagent	Concentrations	For 50 ml
Tris-HCl pH 8.5	10 mM	0.5 ml of 1 M stock

adjust the volume with MilliQ water to 50 ml

Consumables and equipment

Plate centrifuge with swing-out rotor (e.g. Eppendorf Centrifuge 5804R)

Microtiter plate orbital shaker (e.g. IKA MS 3 basic)

Magnetic stand for 96-well plate (e.g. BOMB microplate magnetic rack)

Multichannel pipettes

30 – 300 μ l (e.g. Eppendorf, **Eppendorf Research® plus**, 8-Channel – PN: 3125000052)

50 – 1200 μ l (e.g. VWR, Multi-channel pipette, 8-channel – PN: 613-5422)







96-well PCR plate (e.g. Sarstedt – PN: 72.1979.102)

Seals (e.g. Bio-Rad, Microseal® ‘B’ Adhesive Seals – PN: MSB1001)

Beads Washing procedure

Step	Washing	Time	<input checked="" type="checkbox"/>
1	Resuspend the stock of Sera-Mag carboxylated beads by vortexing. Ensure that the beads are resuspended completely before proceeding forward	1 min	<input type="checkbox"/>
2	Take out 570 μl of beads as quickly as possible (to avoid the beads settling) and transfer them to a new microcentrifuge tube.	1 min	<input type="checkbox"/>
3	Settle the magnetic beads on a magnetic stand and discard the supernatant.	5 min	<input type="checkbox"/>
4	Add 1 ml of MilliQ water. Remove the tube from the magnet, resuspend the beads and centrifuge briefly. Put back the tube on the magnet and pellet the beads	2 min	<input type="checkbox"/>
5	Remove the supernatant and add 1 ml of MilliQ. Remove the tube from the magnetic stand and resuspend the beads. After resuspension, the beads are ready to be used in preparing the PB buffer .	5 min	<input type="checkbox"/>

BOMB Plasmid DNA extraction using Sera-Mag carboxylated beads

Step	Clean-up	Time	<input checked="" type="checkbox"/>
1	Pellet the bacteria from a 5 ml culture in a centrifuge at 6000 x g for 5 minutes. Discard the supernatant.		<input type="checkbox"/>
2	Resuspend the pellet in 100 µl of P1 buffer . Make sure the pellet is completely resuspended.		<input type="checkbox"/>
3	Add 150 µl of P2 buffer , mix by flipping the tube a few times and incubate at room temperature for 5 minutes.	5 min	<input type="checkbox"/>
4	Add 125 µl of P3 buffer , mix by flipping the tube a few times.	1 min	<input type="checkbox"/>
	<i>Ensure a complete neutralization of the sample</i>		
5	Centrifuge for 10 minutes at >14.000 x g	10 min	<input type="checkbox"/>
6	Transfer 350 µl of the supernatant to a new tube. <i>Pipette carefully to avoid transferring the cell debris/precipitate. Transferring cell debris can cause protein contamination.</i>	1 min	<input type="checkbox"/>
			
7	Resuspend the beads in the PB buffer by vortexing. Make sure that all the beads are resuspended before proceeding forward. <i>Ensure the beads are fully resuspended otherwise you might lose your DNA.</i>	1 min	<input type="checkbox"/>
			
8	Add 350 µl of PB buffer , mix by flipping the tube a few times. Incubate on a shaker for 15 min at RT.	15 min	<input type="checkbox"/>
9	Centrifuge the tube briefly (2-3 seconds). Settle the magnetic beads on a magnetic stand and discard the supernatant. <i>Ensure that the beads are completely pelleted</i>	5 min	<input type="checkbox"/>
			
10	Remove the tube from the magnetic stand and add 1 ml of PE buffer . Mix well (by pipetting, or vortex and spin down).	2 min	<input type="checkbox"/>
11	Settle the magnetic beads on a magnetic stand and discard the supernatant.	2 min	<input type="checkbox"/>
12	While the tube is on the magnet, add 1 ml of PE buffer . Wait for 30 seconds and then remove the supernatant.	2 min	<input type="checkbox"/>
13	Remove the tube from the magnetic stand and add 500 µl of PE buffer . Mix well (by pipetting, or vortex and spin down).	2 min	<input type="checkbox"/>
14	Settle the magnetic beads on a magnetic stand and discard the supernatant.	2 min	<input type="checkbox"/>
15	Remove the tube from the magnet and centrifuge it briefly to pellet all the liquid.	1 min	<input type="checkbox"/>
16	Put back the tube on the magnet and using a 10 µl pipette, remove all the remaining liquid with care to not take up any beads.	1 min	<input type="checkbox"/>
17	Put the tube on a heat block and dry the beads for approximately 5 minutes at 37°C. <i>The beads are dry when you see the beads pellet starting to crack. Do not over-dry.</i>	5 min	<input type="checkbox"/>
			
18	Add 50 µl of elution buffer to elute the DNA from the beads. Pipette well to resuspend and make sure that all the beads from the side of the tube are resuspended. Incubate for 10-15 min at 37°C.	15 min	<input type="checkbox"/>
19	Settle the magnetic beads on a magnetic stand and transfer the supernatant to a new tube. <i>Make sure the beads are completely settled before transferring the supernatant. Avoid transferring any beads. If possible, leave some supernatant in the tube to minimize carryover.</i>	5 min	<input type="checkbox"/>
			

Exemplary results




Fig 1: Optimisation of BOMB plasmid extraction using commercial Sera-Mag beads. (A) Comparison of different BOMB protocols with and without PEG, as well as a commercial column-based kit. (B) Variation of binding time in step 8 shows an increase of yield up to 15 min. MW: Gene Ruler DNA Ladder (Thermo).